

2/2 NORMALLY CLOSED - DIRECT ACTING - TOTAL ISOLATION - G 1/2









## **General Features**

Direct acting, total isolation solenoid valve: the operator is totally isolated from the fluid so that the wetted parts are just the body and the lever-seal.

Possibility of manual opening.

Possibility of disassembling for inspection.

Core duly coated by PTFE (polytetrafluoroethylene) based self lubricating material.

Suitable to shut off liquid and gaseous fluids (verify the compatibility of fluid with materials in contact).

Technical Features						
Maximum allowable pressure (PS)	2 bar					
Opening time	~30ms					
Closing time	~30ms					
Fluid temperature	-10°C +90°C					
Max viscosity	5°E (~37 cStokes or mm²/s)					

Materials in Contact with Fluid					
Body	PPS (see notes)				
Sealing	FPM				

Coil					
Continuous Duty		ED 100%			
Encapsulation material		PET (polyethylene terephtalate) fibreglass reinforced			
Insulation class		F (155°C)			
Ambient temperature		-10°C +60°C			
Electric connections		DIN 46340 - 3 poles connector (EN 175301-803)			
Protection degree		IP 65 (EN 60529) with connector			
	DC	12-24V (+10% -5%)			
Voltages	AC	24/50Hz-110/50Hz (120/60Hz)- 230V/50Hz (+10% -15%)			
		(Other voltages and frequencies on request)			


			Differenti	ial pressur	e (bar)	(bar)		Corino and tune		Davier shaperation					
Port	Orifice size			Δрι	max		Kv	Series and type		Power absorption			Sealings	Notes	Weight (kg)
size ISO 228	(mm)	Δp min	Gas	ses	Liqu	uids	(m <sup>3</sup> /h)	Value Cail		AC (VA) DC					
			AC	DC	AC	DC		Valve	Coil	Inrush	Holding	(VV)			
G 1/2	9	0	0,4	0,4	0,4	0,4	1,6	D332V22C	Z130A	44	24	13	FPM	-	0,540

## **Notes**

- Sealings: FPM = Fluoro-carbon elastomer
- Body: PPS (Polyphenylene-sulfide) fibreglass reinforced, WRAS/KTW and NSF approval



## **Spare Parts**



Kit description	Kit P.N.	Consisting of:
Core kit	G31528	Core pos 4 Core return spring pos.5
Lever seal	3037301R	Lever-seal pos. 2
Kit core tube	G31523	Core tube pos. 3 Coil clip
Coil	Z130A	Coil pos. 1

## Installation

- Solenoid valve can be mounted in any position; vertical with coil upwards preferred.
- In case of disassembling for usual maintenance, the fixing screws have to be tightened at 1,5 Nm max torque.
- Maximum driving torque of the pipe fittings for thread connections = 15 Nm.